PBL Project 2

PBL Group 4: Sophia Burgueno, Anika Kulkarni, Valentina Lopez, Ryan Nguyen, Krishna Ravi, Tatum Thompson, Felix Wang

```
% Code Contributors:
% Anika Kulkarni Last Commit: 10/21/2025
% Krishna Ravi Last Commit: 10/20/2025
% Felix Wang
                 Last Commit: 10/5/2025
% General Housekeeping:
% ! Use Tabs for Indents
% Overview
% ACCOUNTING EQUATION: \Psi out = \Psi in [1 - w reabs + w sec]
% <https://ibb.co/356L4rWn>
% Assuming s-s, no rxn
% END GOAL: line plot of flow rates of each component per nephronal unit
% Nephronal unit = pseudomeasure of time
% LIMITATIONS:
% (1) Water flow held constant (no ADH modulation)
% (2) Active/passive transport not explicitly modeled
% (3) Tubuloglomerular feedback not included
function[molar_flow_rates, concs] = kidney_model(C0, snGFR, condition)
% Indices
% -----
% Chemical Constituents
chemicals = ["Na+", "Cl-", "Urea", "Glucose", "K+", "HCO3-", "Mg2+", "PO4
3-", "Creatinine", "Ca2+"];
molec_weights = [22.989, 35.453, 60.056, 180.156, 39.098, 61.020, 24.305,
94.971, 113.12, 40.08]; % For gram conversion; in g/mol
% Nephronal Units
units = ["RC", "PT, S1", "PT, S2", "PT, S3", "DL", "AL", "DT", "CD"];
% RC = Renal Corpuscle
% PT = Proximal Tubule, split into S1, S2, and S3
% DL = Descending Limb
% AL = Ascending Limb
% DT = Distal Tubule
% CD = Collecting Duct
% Corresponds to x-axis for plots
nSeg = length(units);
nSol = length(chemicals);
% Data Matrices
§ ______
```

```
% Fractions derived from a host of literature sources, primarily:
% - Weinstein, A. M. Seldin and Giebisch's The Kidney. Elsevier Inc., 2008.
849-887.1081-1142
% - Vallon, V. Am J Physiol Cell Physiol. 2011 Jan; 300(1): C6-C8.
% - Oregon State University, open courseware
용 {
       Na+
                C1-
                        Urea
                                 Gluc
                                            K+
                                                    HCO3-
                                                              Mq2+
                                                                       PO43-
          Ca2+
Creat
RC \mid (1,1) \mid (1,2) \mid (1,3) \mid (1,4) \mid (1,5) \mid (1,6) \mid (1,7) \mid (1,8) \mid (1,9) \mid
(1,10)
S1 \mid (2,1) \mid (2,2) \mid (2,3) \mid (2,4) \mid (2,5) \mid (2,6) \mid (2,7) \mid (2,8) \mid (2,9) \mid
(2,10)
S2 \mid (3,1) \mid (3,2) \mid (3,3) \mid (3,4) \mid (3,5) \mid (3,6) \mid (3,7) \mid (3,8) \mid (3,9) \mid
(3,10)
S3 \mid (4,1) \mid (4,2) \mid (4,3) \mid (4,4) \mid (4,5) \mid (4,6) \mid (4,7) \mid (4,8) \mid (4,9) \mid
(4,10)
DL \mid (5,1) \mid (5,2) \mid (5,3) \mid (5,4) \mid (5,5) \mid (5,6) \mid (5,7) \mid (5,8) \mid (5,9) \mid
(5,10)
AL \mid (6,1) \mid (6,2) \mid (6,3) \mid (6,4) \mid (6,5) \mid (6,6) \mid (6,7) \mid (6,8) \mid (6,9) \mid
(6,10)
 DT \mid (7,1) \mid (7,2) \mid (7,3) \mid (7,4) \mid (7,5) \mid (7,6) \mid (7,7) \mid (7,8) \mid (7,9) \mid 
(7,10)
CD \mid (8,1) \mid (8,2) \mid (8,3) \mid (8,4) \mid (8,5) \mid (8,6) \mid (8,7) \mid (8,8) \mid (8,9) \mid
(8,10)
용}
% Reabsorption fractions per constituent (of incoming stream) per unit
% This is what's returned to interstitial fluid
% Solutes
                         Cl-,
                                    Urea,
                                              Glucose, K+,
                                                                   HCO3-,
                                                                              Mq2+,
               Na+,
PO43-,
        Creat,
                     Ca2+
                                                                               0,
reabs_frac = [0,
                           0,
                                     0,
                                                0,
                                                          0,
                                                                     0,
0,
                     0;
                            % RC
          0,
                                    0.90,
               0.33,
                                                         0.80,
                                                                              0.35,
    0.33,
                         0,
                                              0,
                                                                   0,
0,
          0.35; % PT, S1
               0.328,
    0.328,
                         0,
                                    0.09,
                                              0,
                                                         0.10,
                                                                   0,
                                                                              0.25,
0,
          0.25; % PT, S2
               0.222,
                                              0.60,
                                                                   0.20,
                                                                              0.10,
    0.222,
                         0.50,
                                    0,
                                                         0,
          0.10; % PT, S3
0,
                                                         0.15,
    0,
               0,
                         0,
                                    0,
                                               0,
                                                                   0,
                                                                              0,
          0;
0,
                 % DL (salt-impermeable)
               0.25,
                                                                   0.7,
    0.25,
                         0,
                                    0,
                                              0.25,
                                                                              0,
0,
          0.20; % AL (water-impermeable, salt-permeable)
    0.05,
               0.05,
                                               0,
                                                         0.05,
                                                                   0.05,
                                                                              0.05,
                         0,
                                    0,
          0.10; % DT
0,
               0,
    0,
                         0,
                                    0,
                                               0,
                                                         0,
                                                                    0,
                                                                              0,
0,
          0.05; % CD
    ];
% Note that Na/Cl reabsorption can increase to 0.02/0.03 when producing
dilute urine (over-hydration); also when high salt intake (need to dilute
urine)
% Note that urea is reabsorbed when producing concentrated urine to conserve
water, as urea establishes an osmotic gradient (de-hydration)
% However, because this is tightly regulated by ADH and other hormones, this
```

```
is outside the scope of this model
reabs frac = max(0, min(reabs frac, 0.999)); % Safety clamp
% Secretion fractions per constituent (of incoming stream) per unit
% This is what's secreted by bloodstream into tubule post-RC (initial
filtration)
% Solutes
                                         Glucose, K+,
                                                           HCO3-,
             Na+,
                      Cl-,
                                Urea,
                                                                     Mg2+,
PO43-,
                  Ca2+
         Creat,
                                                   0,
sec frac =
             [0,
                       0,
                                 0,
                                          0,
                                                            0,
                                                                      0,
0,
                  0; % RC
         0,
             0,
                      0,
                                0,
                                         0,
                                                  0,
                                                            0,
                                                                     0,
0,
         0; % PT, S1
    0,
                      0,
                               0,
                                         0,
                                                  0,
                                                           0,
             0,
                                                                     0,
0.30,
         0; % PT, S2
    0,
             0,
                      0,
                                0,
                                         0,
                                                  0,
                                                            0,
                                                                     0,
         0; % PT, S3
    0,
             0,
                      0.15,
                                0,
                                                  0,
                                                           0,
                                                                     0,
         0; % DL (salt-impermeable)
0,
                                                  0,
                                                           0,
    0,
             0,
                      0,
                                0,
                                         0,
                                                                     0,
         0; % AL (water-impermeable, salt-permeable)
0,
                                                           0,
             0,
    0,
                      0,
                                0,
                                         0.10,
                                                  0,
                                                                     0,
0,
         0; % DT
                               0,
             0,
                      0,
                                         0.10,
                                                  0,
                                                            0,
                                                                     0,
    0,
0,
         0; % CD
    ];
sec_frac = max(0, min(sec_frac, 0.999)); % Safety clamp
% Molar flow rates per constituent per unit
% To be solved for; preallocated for now
molar_flow_rates = zeros(nSeg,nSol);
% Concentrations per constituent per unit
% To be solved for; preallocated for now
concs = zeros(nSeg,nSol); % mmol/L
% Volumetric flow rates per constituent per unit
vol_flow_rates = snGFR * ones(nSeg,1); % mL/min
% Set up so molar flow rate = vol flow rate * conc, so mL/min * mM * 1
L/1000 \text{ mL} = \text{mmol/min}
% Calculations
§ _____
% Initialize input stream to first unit (RC)
concs(1,:) = C0; % mmol/L, aka mM; TAKEN AS INPUT
molar_flow_rates(1,:) = snGFR .* concs(1,:) * 1e-3; % mmol/min; snGFR TAKEN
AS INPUT
% Conditional
% Adjust reabsorption fractions for salt in the case of high salt intake -
whether a one-off event or hypernatremia/hyperchloremia
if concs(1, 1) > 140.0000 && concs(1, 2) > 106
      sec_frac(8,1) = 0.02; % Na+
      sec_frac(8,2) = 0.03; % Cl-
```

```
end
% Math Propagation
% -----
% Propagate flow rates by unit/segment
for i = 2:nSeg
    % Accounting for each chemical constituent
    N in = molar flow rates(i-1,:); % Vector with inflows for all chemicals
(mmol/min)
    N_out = N_in .* (1 - reabs_frac(i,:) + sec_frac(i,:)); % Vector with
outflows for all chemicals
    if any(N out < 0)</pre>
        errordlg("Negative Flow Rate at Row " + i + "!!!")
    end
    % Fill row i of 8x10 matrix
    molar_flow_rates(i,:) = N_out; % Given that P_out is a vector containing
flow rates of all chemicals at that unit
    concs(i,:) = molar_flow_rates(i,:) ./ vol_flow_rates(i); % mmol/min /
mL/min = mmol/L
end
% Outlets in grams/min
grams_per_min_out = zeros(1,nSol);
for j = 1:nSol
    grams_per_min_out(j) = molar_flow_rates(end,j) * molec_weights(j) *
1e-3; % mmol/min * g/mol * 1e-3 = g/min
end
disp("Outlet (collecting duct) in grams/min per solute: ");
    disp(chemicals(k) + ":" + num2str(grams per min out(k)));
end
% Graphs
% Display to check matrix is reasonable
disp('8x10 Molar Flow Rate Matrix (rows = RC, S1, S2, S3, DL, AL, DT, CD;
columns = Na+, Cl-, Urea, Glucose, K+, HCO3-, Mg2+, phosphate, creatinine,
Ca2+):');
disp(molar_flow_rates);
colors = ["#012966", "#005f73", "#0a9396", "#94d2bd", "#e9d8a6", ...
          "#ee9b00", "#ca6702", "#bb3e03", "#ae2012", "#9b2226"];
% Figure 1: Concentrations
figure('Units','normalized','Position',[0.05 0.05 0.9 0.8])
tiledlayout(2, 5, 'TileSpacing','compact', 'Padding','compact')
for k = 1:nSol
    nexttile
    plot(1:nSeg, concs(:,k), '-', 'Color', colors(k), 'LineWidth', 2);
```

```
grid on
    title(chemicals(k) + " Concentration", 'FontWeight', 'bold', 'FontSize',
12)
    xticks(1:nSeg)
    xticklabels(units)
    ylabel('mM')
    ylim('auto')
end
sgtitle({"Solute Concentrations Along Nephron Segments", "Test Case: " +
condition}, 'FontSize', 14, 'FontWeight', 'bold')
% Figure 2: Flow Rates
figure('Units','normalized','Position',[0.05 0.05 0.9 0.8])
tiledlayout(2, 5, 'TileSpacing','compact', 'Padding','compact')
for k = 1:nSol
    nexttile
    plot(1:nSeg, molar_flow_rates(:,k), '-', 'Color', colors(k),
'LineWidth', 2);
    grid on
    title(chemicals(k) + "Flow", 'FontWeight', 'bold', 'FontSize', 12)
    xticks(1:nSeq)
    xticklabels(units)
    ylabel('mmol/min')
    ylim('auto')
end
sgtitle({"Molar Flow Rates Along Nephron Segments", "Test Case: " +
condition}, 'FontSize', 14, 'FontWeight', 'bold')
end
% Test Cases
function[conc_out, snGFR_out] = test_cases(C0, snGFR, condition)
% Implements test cases by adjusting inlet concentrations and single-nephron
GFR accordingly
% condition: 'healthy', 'ckd3b' (CKD, stage 3b), 't2dm early' (early type 2
% diabetes), 't2dm_late' (late type 2 diabetes), 'htn' (hypertension)
% Re-indexing for convenience
Na = 1;
C1 = 2;
Urea = 3;
Gluc = 4;
K = 5;
HCO3 = 6;
Mg = 7;
PO4 = 8;
Creat = 9;
Ca = 10;
```

```
switch lower(condition)
    case 'healthy'
        % No change, using base values
    case 'ckd3b' % Note that we are modeling stage 3b as this marks
substantial loss of kidney function and sure-fire diagnosis of CKD
        snGFR = snGFR * 37/105; % Using a scaling factor as reference as
snGFR values not available
        % Normal GFR = 90-120 mL/min; Stage 3b GFR = 30-44 mL/min
        % Creatinine level increased by 60%
        % Typical creatinine level: 0.7-1.3 mg/dL in males, 0.6-1.1 mg/dL in
females
        % CKD3b creatinine level: 1.2-2.0 mg/dL in males, 1.8-3.0 mg/dL in
females
        % 50-70% increase
       CO(Creat) = CO(Creat) * 1.6;
        % Urea level increased by 40% (estimate)
       CO(Urea) = CO(Urea) * 1.4;
        % Potassium level increased by 15% (estimate; hyperkalemia)
       CO(K) = CO(K) * 1.15;
        % Phosphate level increased by 25% (estimate; due to degradation of
phosphate secretion)
       CO(PO4) = CO(PO4) * 1.25;
        % Bicarbonate level decreased, not significantly (sign of metabolic
acidosis)
       CO(HCO3) = CO(HCO3) * 0.90;
        % Calcium level decreased, not significantly (sign of hypocalcemia)
       CO(Ca) = CO(Ca) * 0.90;
    case 't2dm early' % Separating early and late stages because early T2DM
= hyperfiltration
        snGFR = snGFR * 1.125; % Approximating hyperfiltration
        % Normal GFR = 120 mL/min; Early T2DM GFR = 120-150 mL/min, median
at 135 mL/min
       CO(Gluc) = 7; % 7 mmol/L = 126 mg/dL, as an average plasma
concentration of glucose during early hyperglycemia
    case 't2dm_late' % Separating early and late stages because late T2DM =
hypofiltration
        snGFR = snGFR * 22/105; % Approximating hypofiltration
        % Normal GFR = 90-120 mL/min; Late T2DM GFR = 15-29 mL/min, median
at 22 mL/min (correlated with Stage 4-5 CKD)
       CO(Gluc) = 9.7; % 8.3-11.1 mmol/L, as an average plasma
concentration of glucose during late stage hyperglycemia
       CO(K) = CO(K) * 1.30; % Jumps to greater than 6 mmol/L
       CO(PO4) = CO(PO4) * 1.15; % Jumps to greater than 1.5 mmol/L
```

```
CO(HCO3) = CO(HCO3) * 0.85; % Not a substantial decrease but still
indicative of metabolic acidosis
    case 'htn'
        snGFR = snGFR * 0.90; % Slight decrease to reflect vascular damage
end
conc out = C0;
snGFR_out = snGFR;
end
% Inputs
% BASELINE INLET CONCENTRATIONS
% Inlet filtrate concentrations at renal corpuscle, as INPUT into main
function
C0 = [140.0000, 102.0000, 5.714, 4.6905, 4.3500, 24.0000, 0.8225, 0.3950,
0.0920, 0.5700]; % Na+, Cl-, Urea, Glucose, K+, HCO3-, Mg2+, PO43-,
Creatinine, Ca2+
% In mmol/L
snGFR = 79 / 1000; % nL/min * 1e-3 = mL/min (filtrate into RC/Bowman's
capsule for a healthy kidney)
% A healthy kidney has a single-nephron GFR of approximately 79 +/- 42
nanoliters per minute (nL/min).
% Healthy
[CO_h, sn_h] = test_cases(CO, snGFR, 'healthy');
kidney model(C0_h, sn_h, "Healthy");
% CKD3b
[C0_ckd, sn_ckd] = test_cases(C0, snGFR, 'ckd3b');
kidney model(C0 ckd, sn ckd, "CKD3b");
% T2DM Early
[C0_dme, sn_dme] = test_cases(C0, snGFR, 't2dm_early');
kidney_model(C0_dme, sn_dme, "T2DM (Early)");
% T2DM Late
[C0_dml, sn_dml] = test_cases(C0, snGFR, 't2dm_late');
kidney_model(C0_dml, sn_dml, "T2DM (Late)");
% Hypertension
[C0 htn, sn htn] = test cases(C0, snGFR, 'htn');
kidney_model(C0_htn, sn_htn, "Hypertension");
% Combination of all 3, modeling severe CKD
[C0_tmp, sn_tmp] = test_cases(C0,
                                         snGFR, 'ckd3b');
[C0 tmp, sn tmp] = test cases(C0 tmp, sn tmp, 'htn');
[C0 combo, sn_combo] = test_cases(C0_tmp, sn_tmp, 't2dm_late');
kidney model(C0 combo, sn combo, "CKD3b + HTN + T2DM (Late)");
```

```
Outlet (collecting duct) in grams/min per solute:
Na+:6.3458e-05
Cl-:7.13e-05
Urea:1.5588e-05
Glucose: 6.0749e-06
K+:4.8773e-06
HCO3-:1.6816e-05
Mg2+:3.6008e-07
PO4 3-:1.2353e-06
Creatinine:1.0688e-06
Ca2+:5.4163e-07
8x10 Molar Flow Rate Matrix (rows = RC, S1, S2, S3, DL, AL, DT, CD; columns
= Na+, Cl-, Urea, Glucose, K+, HCO3-, Mg2+, phosphate, creatinine, Ca2+):
  Columns 1 through 7
    0.0111
               0.0081
                         0.0005
                                   0.0004
                                              0.0003
                                                         0.0019
                                                                   0.0001
    0.0074
               0.0054
                         0.0005
                                   0.0000
                                              0.0003
                                                         0.0004
                                                                   0.0001
    0.0050
               0.0036
                         0.0005
                                   0.0000
                                              0.0003
                                                         0.0003
                                                                   0.0001
    0.0039
              0.0028
                         0.0002
                                   0.0000
                                              0.0001
                                                         0.0003
                                                                   0.0001
    0.0039
               0.0028
                         0.0003
                                   0.0000
                                              0.0001
                                                         0.0003
                                                                   0.0001
    0.0029
               0.0021
                         0.0003
                                   0.0000
                                              0.0001
                                                         0.0003
                                                                   0.0000
    0.0028
               0.0020
                         0.0003
                                   0.0000
                                              0.0001
                                                         0.0003
                                                                   0.0000
    0.0028
               0.0020
                         0.0003
                                   0.0000
                                              0.0001
                                                         0.0003
                                                                   0.0000
  Columns 8 through 10
    0.0000
               0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
    0.0000
              0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
Outlet (collecting duct) in grams/min per solute:
Na+:2.2361e-05
C1-:2.5125e-05
Urea:7.6901e-06
Glucose:2.1407e-06
K+:1.9765e-06
HCO3-:5.3331e-06
Mg2+:1.2688e-07
PO4 3-:5.441e-07
Creatinine:6.026e-07
Ca2+:1.7177e-07
8x10 Molar Flow Rate Matrix (rows = RC, S1, S2, S3, DL, AL, DT, CD; columns
= Na+, Cl-, Urea, Glucose, K+, HCO3-, Mg2+, phosphate, creatinine, Ca2+):
  Columns 1 through 7
    0.0039
               0.0028
                         0.0002
                                   0.0001
                                              0.0001
                                                         0.0006
                                                                   0.0000
    0.0026
               0.0019
                         0.0002
                                   0.0000
                                              0.0001
                                                         0.0001
                                                                   0.0000
    0.0018
               0.0013
                         0.0002
                                   0.0000
                                              0.0001
                                                         0.0001
                                                                   0.0000
    0.0014
               0.0010
                         0.0001
                                   0.0000
                                              0.0001
                                                         0.0001
                                                                   0.0000
```


```
0.0014
              0.0010
                         0.0001
                                    0.0000
                                              0.0001
                                                         0.0001
                                                                   0.0000
    0.0010
               0.0007
                         0.0001
                                    0.0000
                                              0.0000
                                                         0.0001
                                                                   0.0000
                         0.0001
                                    0.0000
    0.0010
               0.0007
                                              0.0000
                                                         0.0001
                                                                   0.0000
    0.0010
               0.0007
                         0.0001
                                    0.0000
                                              0.0001
                                                         0.0001
                                                                   0.0000
  Columns 8 through 10
    0.0000
               0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
                         0.0000
    0.0000
              0.0000
    0.0000
               0.0000
                         0.0000
    0.0000
              0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
Outlet (collecting duct) in grams/min per solute:
Na+:7.139e-05
C1-:8.0212e-05
Urea:1.7537e-05
Glucose:1.0199e-05
K+:5.4869e-06
HCO3-:1.8918e-05
Mg2+:4.0508e-07
PO4 3-:1.3897e-06
Creatinine:1.2024e-06
Ca2+:6.0933e-07
8x10 Molar Flow Rate Matrix (rows = RC, S1, S2, S3, DL, AL, DT, CD; columns
= Na+, Cl-, Urea, Glucose, K+, HCO3-, Mg2+, phosphate, creatinine, Ca2+):
  Columns 1 through 7
    0.0124
               0.0091
                         0.0005
                                    0.0006
                                              0.0004
                                                         0.0021
                                                                   0.0001
                         0.0005
    0.0083
               0.0061
                                    0.0001
                                              0.0004
                                                         0.0004
                                                                   0.0001
    0.0056
                         0.0005
                                    0.0001
                                                         0.0004
                                                                   0.0001
               0.0041
                                              0.0004
    0.0044
              0.0032
                         0.0003
                                    0.0001
                                              0.0002
                                                         0.0004
                                                                   0.0001
              0.0032
    0.0044
                         0.0003
                                    0.0001
                                              0.0002
                                                         0.0003
                                                                   0.0001
    0.0033
               0.0024
                         0.0003
                                    0.0001
                                              0.0001
                                                         0.0003
                                                                   0.0000
               0.0023
                         0.0003
                                    0.0001
                                              0.0001
                                                         0.0003
                                                                   0.0000
    0.0031
    0.0031
              0.0023
                         0.0003
                                    0.0001
                                              0.0001
                                                         0.0003
                                                                   0.0000
  Columns 8 through 10
    0.0000
              0.0000
                         0.0001
    0.0000
               0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
    0.0000
              0.0000
                         0.0000
    0.0000
              0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
                         0.0000
    0.0000
               0.0000
              0.0000
                         0.0000
    0.0000
Outlet (collecting duct) in grams/min per solute:
Na+:1.3296e-05
```


C1-:1.4939e-05


```
Glucose: 2.6322e-06
K+:1.3285e-06
HCO3-:2.9949e-06
Mg2+:7.5444e-08
PO4 3-:2.9764e-07
Creatinine:2.2394e-07
Ca2+:1.1348e-07
8x10 Molar Flow Rate Matrix (rows = RC, S1, S2, S3, DL, AL, DT, CD; columns
= Na+, Cl-, Urea, Glucose, K+, HCO3-, Mg2+, phosphate, creatinine, Ca2+):
  Columns 1 through 7
    0.0023
               0.0017
                         0.0001
                                    0.0002
                                              0.0001
                                                         0.0003
                                                                    0.0000
    0.0016
               0.0011
                         0.0001
                                    0.0000
                                              0.0001
                                                         0.0001
                                                                    0.0000
    0.0010
               0.0008
                         0.0001
                                    0.0000
                                              0.0001
                                                         0.0001
                                                                    0.0000
    0.0008
               0.0006
                         0.0000
                                    0.0000
                                              0.0000
                                                         0.0001
                                                                    0.0000
    0.0008
              0.0006
                         0.0001
                                    0.0000
                                              0.0000
                                                         0.0001
                                                                    0.0000
                         0.0001
                                    0.0000
                                                         0.0001
                                                                    0.0000
    0.0006
               0.0004
                                              0.0000
    0.0006
               0.0004
                         0.0001
                                    0.0000
                                              0.0000
                                                         0.0000
                                                                    0.0000
    0.0006
               0.0004
                         0.0001
                                    0.0000
                                              0.0000
                                                         0.0000
                                                                    0.0000
  Columns 8 through 10
    0.0000
               0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
               0.0000
    0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
    0.0000
               0.0000
                         0.0000
Outlet (collecting duct) in grams/min per solute:
Na+:5.7112e-05
C1-:6.417e-05
Urea:1.4029e-05
Glucose:5.4674e-06
K+:4.3896e-06
HCO3-:1.5135e-05
Mg2+:3.2407e-07
PO4 3-:1.1117e-06
Creatinine:9.6192e-07
Ca2+:4.8747e-07
8x10 Molar Flow Rate Matrix (rows = RC, S1, S2, S3, DL, AL, DT, CD; columns
= Na+, Cl-, Urea, Glucose, K+, HCO3-, Mg2+, phosphate, creatinine, Ca2+):
  Columns 1 through 7
    0.0100
               0.0073
                         0.0004
                                    0.0003
                                              0.0003
                                                         0.0017
                                                                    0.0001
    0.0067
               0.0049
                         0.0004
                                    0.0000
                                                         0.0003
                                              0.0003
                                                                    0.0001
    0.0045
               0.0033
                         0.0004
                                    0.0000
                                              0.0003
                                                         0.0003
                                                                    0.0001
    0.0035
               0.0025
                         0.0002
                                    0.0000
                                              0.0001
                                                         0.0003
                                                                    0.0000
    0.0035
               0.0025
                         0.0002
                                    0.0000
                                              0.0001
                                                         0.0003
                                                                    0.0000
    0.0026
               0.0019
                         0.0002
                                    0.0000
                                              0.0001
                                                         0.0003
                                                                    0.0000
                         0.0002
    0.0025
               0.0018
                                    0.0000
                                              0.0001
                                                         0.0002
                                                                    0.0000
```


Urea:3.2661e-06


```
0.0025
              0.0018
                         0.0002
                                   0.0000
                                              0.0001
                                                        0.0002
                                                                   0.0000
  Columns 8 through 10
    0.0000
              0.0000
                         0.0000
    0.0000
              0.0000
                         0.0000
    0.0000
              0.0000
                         0.0000
    0.0000
              0.0000
                         0.0000
    0.0000
              0.0000
                         0.0000
                         0.0000
    0.0000
              0.0000
    0.0000
              0.0000
                         0.0000
    0.0000
              0.0000
                         0.0000
Outlet (collecting duct) in grams/min per solute:
Na+:4.2167e-06
Cl-:4.7378e-06
Urea:1.4501e-06
Glucose:8.3479e-07
K+:4.8451e-07
HCO3-:8.5482e-07
Mg2+:2.3927e-08
PO4 3-:1.1799e-07
Creatinine:1.1363e-07
Ca2+:3.2392e-08
8x10 Molar Flow Rate Matrix (rows = RC, S1, S2, S3, DL, AL, DT, CD; columns
= Na+, Cl-, Urea, Glucose, K+, HCO3-, Mg2+, phosphate, creatinine, Ca2+):
   1.0e-03 *
  Columns 1 through 7
    0.7349
              0.5354
                         0.0420
                                   0.0509
                                              0.0341
                                                        0.0964
                                                                   0.0043
    0.4924
              0.3587
                         0.0420
                                   0.0051
                                              0.0341
                                                        0.0193
                                                                   0.0043
    0.3309
              0.2411
                         0.0420
                                   0.0046
                                              0.0341
                                                        0.0173
                                                                   0.0043
    0.2574
                         0.0210
                                                        0.0173
              0.1876
                                   0.0046
                                              0.0137
                                                                   0.0035
    0.2574
              0.1876
                         0.0241
                                   0.0046
                                              0.0137
                                                        0.0147
                                                                   0.0035
                                                                   0.0010
    0.1931
              0.1407
                         0.0241
                                   0.0046
                                              0.0102
                                                        0.0147
    0.1834
              0.1336
                         0.0241
                                   0.0046
                                              0.0113
                                                        0.0140
                                                                   0.0010
                         0.0241
                                   0.0046
                                                        0.0140
                                                                   0.0010
    0.1834
              0.1336
                                              0.0124
  Columns 8 through 10
    0.0030
              0.0008
                         0.0027
    0.0019
              0.0008
                         0.0018
    0.0015
              0.0010
                         0.0013
              0.0010
                         0.0012
    0.0013
    0.0013
              0.0010
                         0.0012
    0.0013
              0.0010
                         0.0009
    0.0012
              0.0010
                         0.0009
    0.0012
                         0.0008
              0.0010
```





























Published with MATLAB® R2025a